


















ΟΔΗΓΙΕΣ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ

ASSEMBLING INSTRUCTIONS




 ax12	 bx12	 cx10	 dx20	 ex3	 fx20	 gx12	 hx6	 ix8	 jx3
 kx3	 lx2	 mx2	 nx2						


1




2




3




4




5




6




7




8



9



10



11

